

P20-3100

START BOOSTER



REVERSE POLARITY ALARM

This audible and visual alert informs professionals of incorrect terminal connections.

LED CHARGE INDICATOR

The test button allows users to easily check the charge level of the booster and test the alternator of a vehicle.

INBUILT SAFETY FUSE

Pure brass clamps with braided connection protected by a safety fuse.

RIBBED ABS CHASSIS

Reinforced internal structure provides strength and durability making a dependable chassis.



AGM 12V

Model	Volts	Peak Amps (A)	Starting Amps (A)	# Of Batteries	Location of Fuse	Fuse (A)	Dimensions (cm)	Cable Diameter (mm ²)	Cable Reach (cm)	Unit Weight (KG)	Charger Voltage (V)	Charger Amps (A)	Vehicle Types
P20-3100	12V	3100A	1170A	1	CLAMP	500A	36x16x42	25	190	12.3	230	2	